# DNPIO-CO-CC Ordering Guide

Rev. 04 updated 15 May 2008

Ordering Code: DNPIO-CO-CC- _ _ _ _

DNPIO-CO-CC- _ _ _ _

| | | | | |
|---|---|---|---|---|
| | | | | **CO TERMINATION OPTIONS** |
| 1 | | | | (1) - Compression Termination |
| 2 | | | | (2) - D25 Termination |
| 3 | | | | (3) - Disconnectable Compression Termination |
| 4 | | | | (4) - Solid State Relays |
| | | | | **Output Configuration** |
| | A | | | (A) - Trip / Close |
| | B | | | (B) - Raise / Lower |
| | | | | **DUCT PANEL OPTIONS** |
| | | U | | (U) - DUCT PANEL NOT REQUIRED |
| | | 1 | | (1) - CABLE DUCT PANEL, TIE WRAP CONNECTIONS |
| | | 2 | | (2) - TWO CABLE DUCT PANELS, TIE WRAP CONNECTIONS |
| | | 3 | | (3) - CABLE DUCT PANEL, NO THROUGH HOLES |
| | | 4 | | (4) - TWO CABLE DUCT PANELS, NO THROUGH HOLES |
| | | 5 | | (5) - CABLE DUCT PANEL, THROUGH HOLES AT EACH END |
| | | 6 | | (6) - TWO CABLE DUCT PANELS, THROUGH HOLES AT EACH END |
| | | | | **CO Optional Components** |
| | | | U | (U) - Option not required |
| | | | 1 | (1) - DNP I/O MODULE INSTALLATION & MAINTENANCE GUIDE |
| | | | 2 | (2) - CABLE, IP SERVER TO FIRST DNP I/O MODULE |
| | | | 3 | (3) - CABLE, IBOX TO FIRST DNP I/O MODULE |
| | | | 4 | (4) - CABLE, DNP I/O MODULE TO DNP I/O MODULE |
| | | | 5 | (5) - CABLE, LAST DNP I/O MODULE |

GE Energy reserves the right to make any changes to the ordering guide without notice

For the most recent version of the order guide, please visit the GE T&D website at:
http://www.gepower.com/prod_serv/products/substation_automation/en/index.htm