

B.1.1 LIST OF TABLES

TABLE: 1-1 ORDER CODES	1-10
TABLE: 2-1 REVISION HISTORY TABLE.....	2-3
TABLE: 2-2 PQM EXTERNAL CONNECTIONS	2-4
TABLE: 3-1 RESET KEY ACTIONS	3-5
TABLE: 4-1 SETPOINT ACCESS CONDITIONS.....	4-5
TABLE: 4-2 ANALOG OUTPUT SELECTION CRITERIA	4-23
TABLE: 4-3 ANALOG OUTPUT PARAMETERS.....	4-24
TABLE: 4-4 AUXILIARY RELAYS ACTIVATION PRIORITY.....	4-35
TABLE: 5-1 LIST OF POSSIBLE EVENTS	5-28
TABLE: 7-1 MASTER/SLAVE PACKET FORMAT FOR FUNCTION CODE 03H/04H	7-4
TABLE: 7-2 MASTER/SLAVE PACKET FORMAT FOR FUNCTION CODE 05H.....	7-5
TABLE: 7-3 MASTER/SLAVE PACKET FORMAT FOR BROADCAST COMMAND	7-6
TABLE: 7-4 MASTER/SLAVE PACKET FORMAT FOR FUNCTION CODE 06H.....	7-7
TABLE: 7-5 MASTER/SLAVE PACKET FORMAT FOR FUNCTION CODE 07H.....	7-8
TABLE: 7-6 MASTER/SLAVE PACKET FORMAT FOR FUNCTION CODE 08H.....	7-9
TABLE: 7-7 MASTER/SLAVE PACKET FORMAT FOR FUNCTION CODE 10H.....	7-10
TABLE: 7-8 MASTER/SLAVE PACKET FORMAT FOR PERFORMING COMMANDS.....	7-11
TABLE: 7-9 PACKET FORMAT FOR FUNCTION CODE 16 BROADCAST COMMAND.....	7-12
TABLE: 7-10 PQM MEMORY MAP	7-15
TABLE: 7-11 MEMORY MAP DATA FORMATS	7-55
TABLE: 7-12 ANALOG OUTPUT PARAMETER RANGE FOR SERIAL PORTS	7-63
TABLE: 8-1 POINT LIST FOR ANALOG INPUT/OUTPUT CHANGE	8-9
TABLE: 9-1 PQM SETPOINTS.....	9-1
TABLE: A-1 DATA LOG PARAMETERS.....	A-15

B.1.2 LIST OF FIGURES

FIGURE 1-1: PQM FEATURE HIGHLIGHTS.....	1-2
FIGURE 1-2: SINGLE LINE DIAGRAM	1-3
FIGURE 1-3: DOWNLOADING PRODUCT ENHANCEMENTS VIA THE SERIAL PORT	1-4
FIGURE 1-4: ADDITIONAL COMMUNICATION PORT.....	1-5
FIGURE 1-5: SWITCH INPUTS AND OUTPUTS RELAYS.....	1-6
FIGURE 1-6: HARMONIC SPECTRUM.....	1-7
FIGURE 1-7: CAPTURED WAVEFORM	1-7
FIGURE 1-8: DATA LOGGER	1-8
FIGURE 1-9: TRACE MEMORY TRIGGERS	1-8
FIGURE 1-10: TRACE MEMORY CAPTURE.....	1-9
FIGURE 2-1: PHYSICAL DIMENSIONS.....	2-1
FIGURE 2-2: PRODUCT LABEL	2-2
FIGURE 2-3: REAR TERMINALS.....	2-5
FIGURE 2-4: WIRING DIAGRAM 4-WIRE WYE (3 VTs)	2-6
FIGURE 2-5: WIRING DIAGRAM 4-WIRE WYE (2 VTs)	2-7
FIGURE 2-6: WIRING DIAGRAM 4-WIRE WYE DIRECT (NO VTs).....	2-8
FIGURE 2-7: WIRING DIAGRAM 3-WIRE DELTA (2 VTs)	2-9
FIGURE 2-8: WIRING DIAGRAM 3-WIRE DIRECT (NO VTs).....	2-10
FIGURE 2-9: SINGLE PHASE CONNECTION.....	2-11
FIGURE 2-10: ALTERNATE CT CONNECTIONS FOR 3-WIRE SYSTEM.....	2-12
FIGURE 2-11: SWITCH INPUT CIRCUIT.....	2-15
FIGURE 2-12: ANALOG INPUT MULTIPLEXING	2-16
FIGURE 2-13: ANALOG OUTPUT.....	2-17
FIGURE 2-14: RS485 COMMUNICATION WIRING.....	2-19
FIGURE 2-15: RS232 CONNECTION	2-20
FIGURE 2-16: HI-POT TESTING.....	2-21
FIGURE 3-1: FRONT PANEL	3-1
FIGURE 3-2: DISPLAY	3-1
FIGURE 3-3: STATUS INDICATORS	3-2

FIGURE 3-4: FRONT PANEL KEYS.....	3-4
FIGURE 3-5: MESSAGE KEY OPERATION	3-6
FIGURE 4-1: SETPOINT MESSAGE ORGANIZATION	4-2
FIGURE 4-2: SETPOINTS PAGE 1 – PQM SETUP \ PREFERENCES	4-3
FIGURE 4-3: SETPOINTS PAGE 1 – PQM SETUP / SETPOINT ACCESS	4-4
FIGURE 4-4: SETPOINTS PAGE 1 – PQM SETUP / COMMUNICATION PORTS	4-6
FIGURE 4-5: SETPOINTS PAGE 1 – PQM SETUP / DNP COMMUNICATIONS	4-7
FIGURE 4-6: SETPOINTS PAGE 1 – PQM SETUP / CLOCK.....	4-8
FIGURE 4-7: SETPOINTS PAGE 1 – PQM SETUP / CALCULATION PARAMETERS	4-9
FIGURE 4-8: SETPOINTS PAGE 1 – PQM SETUP / CLEAR DATA	4-11
FIGURE 4-9: SETPOINTS PAGE 1 – PQM SETUP / EVENT RECORDER	4-13
FIGURE 4-10: SETPOINTS PAGE 1 – PQM SETUP / TRACE MEMORY.....	4-14
FIGURE 4-11: SETPOINTS PAGE 1 – PQM SETUP / PROGRAMMABLE MESSAGE	4-17
FIGURE 4-12: SETPOINTS PAGE 1 – PQM SETUP / PRODUCT OPTIONS	4-18
FIGURE 4-13: SETPOINTS PAGE 2 – SYSTEM SETUP / CURRENT/VOLTAGE CONFIGURATION.....	4-19
FIGURE 4-14: SETPOINTS PAGE 2 – SYSTEM SETUP / ANALOG OUTPUTS	4-22
FIGURE 4-15: SETPOINTS PAGE 2 – SYSTEM SETUP / ANALOG INPUT.....	4-25
FIGURE 4-16: SETPOINTS PAGE 2 – SYSTEM SETUP / SWITCH INPUTS	4-27
FIGURE 4-17: SETPOINTS PAGE 2 – SYSTEM SETUP / PULSE OUTPUT	4-29
FIGURE 4-18: PULSE OUTPUT TIMING	4-30
FIGURE 4-19: SETPOINTS PAGE 2 – SYSTEM SETUP / PULSE INPUT.....	4-31
FIGURE 4-20: SETPOINTS PAGE 2 – SYSTEM SETUP / DATA LOGGER	4-33
FIGURE 4-21: SETPOINTS PAGE 3 – OUTPUT RELAYS	4-34
FIGURE 4-22: SETPOINTS PAGE 4 – ALARMS/CONTROL / CURRENT/VOLTAGE	4-37
FIGURE 4-23: PHASE REVERSAL FOR 4-WIRE & 3-WIRE DIRECT CONNECTIONS	4-40
FIGURE 4-24: PHASE REVERSAL FOR 3-WIRE DELTA (2 VTs OPEN-DELTA) CONNECTION	4-40
FIGURE 4-25: SETPOINTS PAGE 4: ALARMS/CONTROL / TOTAL HARMONIC DISTORTION	4-41
FIGURE 4-26: SETPOINTS PAGE 4 – ALARMS/CONTROL / FREQUENCY	4-42
FIGURE 4-27: SETPOINTS PAGE 4 – ALARMS/CONTROL / POWER	4-43
FIGURE 4-28: SETPOINTS PAGE 4 – ALARMS/CONTROL / POWER FACTOR	4-45
FIGURE 4-29: CAPACITOR BANK SWITCHING	4-46
FIGURE 4-30: SETPOINTS PAGE 4 – ALARMS/CONTROL / DEMAND	4-48
FIGURE 4-31: SETPOINTS PAGE 4 – ALARMS/CONTROL / PULSE INPUT	4-50
FIGURE 4-32: SETPOINTS PAGE 4 – ALARMS/CONTROL / TIME	4-52
FIGURE 4-33: SETPOINTS PAGE 4 – ALARMS/CONTROL / MISCELLANEOUS	4-53
FIGURE 4-34: SETPOINTS PAGE 5 – TESTING.....	4-54
FIGURE 4-35: SETPOINTS PAGE 5 – TESTING / CURRENT/VOLTAGE SIMULATION	4-55
FIGURE 4-36: SETPOINTS PAGE 5 – ANALOG OUTPUT SIMULATION	4-56
FIGURE 4-37: SETPOINTS PAGE 5 – ANALOG INPUT SIMULATION	4-57
FIGURE 4-38: SETPOINTS PAGE 5 – TESTING / SWITCH INPUTS SIMULATION	4-58
FIGURE 5-1: ACTUAL VALUES MESSAGE ORGANIZATION.....	5-1
FIGURE 5-2: ACTUAL VALUES – METERING / CURRENT.....	5-2
FIGURE 5-3: ACTUAL VALUES PAGE 1 – METERING / VOLTAGE	5-4
FIGURE 5-4: ACTUAL VALUES PAGE 1 – METERING/PHASORS.....	5-6
FIGURE 5-5: ACTUAL VALUES PAGE 1 – METERING/POWER.....	5-9
FIGURE 5-6: POWER MEASUREMENT CONVENTIONS.....	5-11
FIGURE 5-7: ACTUAL VALUES PAGE 1 – METERING / ENERGY	5-12
FIGURE 5-8: ACTUAL VALUES PAGE 1 – METERING / DEMAND.....	5-14
FIGURE 5-9: ACTUAL VALUES PAGE 1 – METERING / FREQUENCY	5-16
FIGURE 5-10: ACTUAL VALUES PAGE 1 – METERING / PULSE COUNTER.....	5-17
FIGURE 5-11: PULSE INPUT TIMING	5-18
FIGURE 5-12: ACTUAL VALUES PAGE 1 – METERING / ANALOG INPUT	5-19
FIGURE 5-13: ACTUAL VALUES PAGE 2 – STATUS / ALARMS	5-22
FIGURE 5-14: ACTUAL VALUES PAGE 2 – SWITCH STATUS.....	5-22
FIGURE 5-15: ACTUAL VALUES PAGE 2 – CLOCK.....	5-23
FIGURE 5-16: ACTUAL VALUES PAGE 2 – PROGRAMMABLE MESSAGE.....	5-23
FIGURE 5-17: ACTUAL VALUES PAGE 3 – POWER QUALITY VALUES.....	5-24
FIGURE 5-18: ACTUAL VALUES PAGE 3 – TOTAL HARMONIC DISTORTION.....	5-25
FIGURE 5-19: ACTUAL VALUES PAGE 3 – DATA LOGGER	5-26

FIGURE 5–20: ACTUAL VALUES PAGE 3 – EVENT RECORDER	5-27
FIGURE 5–21: ACTUAL VALUES PAGE 4 – SOFTWARE VERSIONS	5-31
FIGURE 6–1: PQMPC COMMUNICATIONS USING THE FRONT RS232 PORT.....	6-1
FIGURE 6–2: PQMPC COMMUNICATIONS USING REAR RS485 PORT	6-2
FIGURE 6–3: PQMPC MENUS	6-6
Figure A–1: DATA LOGGER MEMORY STRUCTURE	A-12
Figure A–2: DATA LOG CONFIGURATION.....	A-13
Figure A–3: MULTIPLE METERING LOCATIONS.....	A-19

B